

Assembly Instructions

Model: RC4531

Step 1

Attach the seat assembly to the sideframes using (4) 3" chair screws in pre-drilled holes
Note: notches in seat face front

Step 2

Attach the back assembly to the sideframes using (4) 3" chair screws in pre-drilled holes

Step 3

Attach the front and rear braces to the sideframes using (4) 3" chair screws in pre-drilled holes

Step 4


Attach rocker bottoms to the sideframes using (4) 3" chair screws in pre-drilled holes

* Tighten all bolts at this time

- (2) Sideframe
- (2) Rocker bottom
- (1) Seat
- (1) Back
- (2) Brace
- (2) Finials
- (1) Hardware pack

TOOLS NEEDED

4mm HEX KEY: INCLUDED



Qty.	Description
16	A - 3" CHAIR SCREW

