


Assembly Instructions

Model: NCL32, NCH38

*NCL32 shown

Step 1

Remove and discard two clear rubber disks.
They are used for protection during shipping.



Clear rubber disks