20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:

Cleaning Tips

For a Quick Clean:
Simply wipe down with soap and water.

For a Deep Clean:
Wipe on ⅓ bleach and ⅔ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:
Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ⅓ bleach and ⅔ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions




PREMIUM POLY PATIOS

KBN36

Kids Lakeside Bench


View this product online at Premium Poly Patios


TOOLS



4mm T-handle
hex key (included)


PARTS






2" Screw — H.27X2


1




2



3



4



5



Remove protective plastic film from the logo medallion.



PREMIUM POLY PATIOS

View this product online at Premium Poly Patios

POLYWOOD®