20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:

Cleaning Tips

For a Quick Clean:
Simply wipe down with soap and water.

For a Deep Clean:
Wipe on ⅓ bleach and ⅔ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:
Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ⅓ bleach and ⅔ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions

PWLD Leg Kit







PWLD
For Use With Dining Tables
-
FDT30, FDT37, FDT3048, RT236, RT248, NCT37, NCT44

PREMIUM POLY PATIOS

View this product online at Premium Poly Patios


TOOLS




4mm T-handle
hex key (included)


3/8" wrench
(not included)

PARTS




Separate box






3" Screw – H.27X3



2.5" Screw — HHW14X2.5


1



Do not over-tighten


FDT37 shown for parts and assembly

2




Do not over-tighten


3



4



Removable table plug
may be included



POLYWOOD®

View this product online at Premium Poly Patios

20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:

Cleaning Tips


For a Quick Clean:
Simply wipe down with soap and water.

For a Deep Clean:
Wipe on ⅓ bleach and ⅔ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.


For a High-Power Clean:
Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ⅓ bleach and ⅔ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions



EMD240
Edge Woven Dining Arm Chair




EMD250
Edge Woven High-Back Dining Arm Chair

PREMIUM POLY PATIOS


View this product online at Premium Poly Patios

TOOLS




4mm T-handle
hex key (included)

PARTS




A x 8

.81" Screw — H.27x.81




B x 4

2.5" Screw — H.27X2.5




C x 4

1.75" Bolt — H.25-20X1.75



D x 8

Screw Plug, Wafer — HSPWAFER




E x 2


1.25X2X.13 Plate - P15515-AL

View this product online at Premium Poly Patios


1




2




3




4



5



6



Remove protective plastic film from the logo medallion.

PREMIUM POLY PATIOS