



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:



Cleaning Tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:


Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:


Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions




QLD200, QLD202
Quattro Dining
Adirondack Chair



QLU200, QLU202
Quattro Upright
Adirondack Chair

TOOLS




4mm T-handle
hex key (included)



4mm hex key
(included)

PARTS



A


x4



2.5" Screw — H.27X2.5


B

x2




3" Screw — H.27X3


1





2




3



4



QLD200, QLU200



QLD202, QLU202



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:



Cleaning Tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:


Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:


Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions




PL36-T1L1
Farmhouse Trestle
65\"



PL36-T1L3
Farmhouse 65\"
Side Bench

TOOLS




4mm T-handle
hex key (included)



3/8" wrench
(not included)

PARTS




A x 8





2.5" Screw — HHW14X2.5

B x 4





2.5" Screw — H.27X2.5

1




A x 4

2



A x 4


3



B



B

4



B

B



Remove protective plastic
film from the logo medallion.



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:



Cleaning Tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®


Assembly Instructions




L1D83, L1R83, L1B83

For Use With Rectangle
Plank Tables-PL83

TOOLS




3/8" wrench
(not included)



4mm T-handle
hex key (included)


PARTS



Separate box




A x 8



2.5" Screw — HHW14X2.5


B x 8





3" Screw — H.27X3

1

Align each screw with a
pilot hole and partially
thread by hand before
fully tightening



2



If legs have
relaxed during
transit, they
may be guided
into pilot hole
alignment

Removable table
plug included



Remove protective plastic
film from the logo medallion.