


# Assembly Directions for Swings

#PLTS4800, #PLTS6000, #PCTS4800, #PZTS4800



## PACKAGE CONTENTS


- 1 Back
- 1 Seat
- 2 Arms
- 1 Hardware Package

## HARDWARE PACKAGE


- 2 5/16" x 3 1/2" Carriage Bolts
- 2 5/16" x 4" Carriage Bolts
- 2 1/4" x 3 1/2" Carriage Bolts
- 3 1/4" x 3" Carriage Bolts
- 4 5/16" Flange Nuts
- 8 5/16" Washers
- 4 5/16" Lock Nuts
- 5 1/4" Flange Nuts
- 2 5/16" x 3" Eye Screws
- 4 5/16" Acorn Nuts

## TOOLS NEEDED:


- Hammer
- 7/16" Wrench
- 1/2" Wrench



Use to measure bolts



1/4" x 3" Carriage Bolts




## STEP #1 -


With the Seat and Back lying face up, install the 1/4" x 3" Carriage Bolts through the pre-drilled holes.

Please note: Loosely tighten the Flange Nuts on the Carriage Bolts.


**STEP #2 -** Attach the Arm Assembly to the Seat and Back using a  $\frac{5}{16}$ " x 4" Carriage Bolt at the seat and a  $\frac{5}{16}$ " x  $3\frac{1}{2}$ " Carriage Bolt at the Arm.



**STEP #3 -** Install the Eye Screw into the pre-drilled hole (see Diagram C). Attach the chain to the Carriage Bolts using Washers and Lock Nuts (see Diagrams A and B).



**STEP #4 -** Repeat Steps 3 and 4. Firmly tighten the Flange Nuts from Step 1.



Your Swing is complete!




Diagram A




Diagram B




Diagram C

