Assembly Directions for Gliders






Single Comfo-Back Glider

Single Cozi-Back Glider



Single Casual-Back Glider



STEP #1 -

Fasten the Leg Assembly to the Seat and Back using Carriage Bolts. Install 2- 5/16" x 21/2" Carriage Bolts in the pre-drilled holes (see Glider Brookst Disgraps)

in the pre-drilled holes (see Glider Bracket Diagram).

1/4" x 4½" Carriage Bolts

1/4" x 3½" Carriage Bolts

STEP #2 - Turn the Chair on the other side and repeat Step 1. 1/4" x 41/2" Carriage Bolts 1/4" x 3" Carriage Bolts


PACKAGE CONTENTS

- 2 Bases
- 1 Back
- 1 Seat
- 1 Hardware Package
- 2 Arms with Legs
- 2 Cross Supports
- 4 Stops
- 1 Glider Bracket Package

HARDWARE PACKAGE

1/4" x 31/2" Carriage Bolts

- 2 ¼" x 4½" Carriage Bolts
- 2 ¼" x 3½" Carriage Bolts
- 6 1/4" x 3" Carriage Bolts
- 8 ¼" x 2" Carriage Bolts
- 8 5/16" x 21/2" Carriage Bolts
- 8 5/16" Lock Nuts
- 8 5/16" Flange Nuts
- 18 ¼" Flange Nuts
- 4 5/16" Acorn Nuts
- 4 Glider Brackets



CORRECT INCORRECT Firmly tap bolts into pre-drilled holes before tightening.

TOOLS NEEDED:
Hammer

7/16" Wrench


1/2" Wrench

www.Poly-Lumber-Furniture.com


Assembly Directions for Glider Base

STEP #1 -

Fasten the two Cross Supports to the Base using ¼" x 2" Carriage Bolts.




STEP #2 - Attach the four Glider Stops to the Base using ½" x 3" Carriage Bolts.







Glider Bracket Diagram




Install the 4- 5/16" x 2½" Carriage
Bolts into the predrilled holes and tighten with 5/16"
Flange Nuts.
Place the Glider
Brackets onto the Carriage Bolt and use 5/16" Lock
Nuts to secure the Glider Brackets.

STEP #4 -

Set the Chair on top of the Base. Attach the Leg of the Chair onto the Glider Bracket using 5/16" Lock Nuts to secure the Glider Brackets.







Use to measure bolts